## IT1080C Computer Networking Packet Tracer Lab 4

## Create a local area network in Packet Tracer.

In this lab, create a local area network composed of five departments plus a DMZ. Assign each LAN private IP address range in the 192.168.x.x range with a CIDR of 24 (subnet mask 255.255.255.0).

In Packet Tracer, create a local area network with six switches connected to a single router.


- 1. Use six Switch 2950-24 (24 interfaces) switches
- 2. Use PT-Router-Empty and add six 1CGE (Gigabit Ethernet) modules
- 3. Add two PC-PTs to each department and attach a Server-PT on the DMZ

NOTE: Annotate all configurations on the network diagram.

Annotate the subnet private IP address and CIDR on the network diagram.


- a) DMZ 192.168.0.0/24
- b) Exec Staff 192.168.1.0/24
- c) Human Relations 192.168.2.0/24
- d) Finance & Accounting 192.168.3.0/24
- e) Manufacturing 192.168.4.0/24
- f) Sales 192.168.5.0/24

Annotate the IP address for each host on the network diagram as shown in the figure below.




## Configuring devices:


1. Assign the first available IP address from each subnet to the default gateway.



2. Statically assign the IP address, subnet mask, and default gateway to each device.



- 3. Connect switches to the router using a Copper Straight-Through cable.
- 4. Connect each device to its switch using a Copper Straight-Through cable.
- 5. Modify the index.html page to reflect your name and a personalized greeting.



Test to ensure each device can communicate on the network.

